
18.17
89
All Devices
Manage
Filter All
(40)
ON | OFF
Dimmer Module
18.17
89
Dimmer Module



Total Control

Total Brightness: 100%

Dimmer1 >

Brightness: 100%



Dimmer2 >

Brightness: 100%



Dimmer Module



Dimmer1

Brightness: 100%

Power
Schedule
Timer
setting
18.18
89



Dimmer1

More Setting

The following setting is the universal function for all dimming paths. After setting, each path will take effect synchronously

Power-on Status Setting: Power-on OFF



18.37

87

Dimmer1

Seesaw Toggle Switch



Set the brightness range of the dimmer

After setting the brightness range, dim and switch the lamp. If the light flashes and goes out during operation, increase the minimum brightness until it does not flash and go out.

20%-100%

Save
Click To

unlock



18.34
88

Dimmer1

Seesaw Toggle Switch

Reselect

Set the brightness range of the dimmer

After setting the brightness range, dim and switch the lamp. If the light flashes and goes out during operation, increase the minimum brightness until it does not flash and go out.

20%-100%


Save
Editable
Save


Select Led Type
1
Seesaw Toggle Switch
Seesaw Sync Switch
2
Kick Back Switch ✓
Cancel
Confirm


18.18
89
Dimmer1
Kick Back Switch
Reselect



Set the brightness range of the dimmer

After setting the brightness range, dim and switch the lamp. If the light flashes and goes out during operation, increase the minimum brightness until it does not flash and go out.

20%-100%

Save
Editable